



P1 = Evenly distributed load
P2 = Point load

Max load / bracket		
P1 = kg	P2 = kg	Torque = Nm
150	75	230

